

This Operation Guide provides details on using the ProVisionaire Control template file (Divide/Combine Room edition) for RM-CR. This template file is used when switching between presets (i.e., room divide/combine settings specified using the wizard) that were saved with the Divide/Combine Room function of RM Device Finder.

ProVisionaire Control is an application that allows you to operate a compatible system from a Windows computer via a wired LAN or a Wi-Fi network. Compatible sound systems may consist of CL/QL/TF, MTX/MRX, RM-CG/RM-CR, etc. You can design a control panel by freely arranging various widgets such as buttons and sliders, allowing you to create custom panels to suit your needs.

Important

- Customize the registered devices and icons in the template file to suit your operating environment.

Notice





- All copyrights for the project file (for the template) and for the Operation Guide are the property of Yamaha Corporation.
- Unauthorized copying or modification of the Operation Guide in part or in whole is prohibited.
- Yamaha Corporation assumes no responsibility for any results or consequences that may arise from the use of this project file (for the template) and of the Operation Guide.
- All of the illustrations and screen shots in this Operation Guide are provided for the sole purpose of explaining operations. For this reason, they may differ from the actual specifications.
- For the purpose of improvement, the application software and project file (for the template) may be updated without notice. Refer to the Yamaha website for the latest information.

Note

- Windows is a registered trademark of Microsoft Corporation in the United States and other countries.
- Company names and product names appearing in this Operation Guide are the trademarks or registered trademarks of their respective owners.


About Divide/Combine Room

The Divide/Combine Room function uses ADECIA's preset function to switch settings when one room is divided into variable partitions, etc. Shown below are system examples where one room is divided into two as well as examples of icons used in Provisionaire Control to recall the preset settings of each system.

	System examples	Icon examples
Divided	 <p>Room1 Room2</p> <p>— Ethernet cable — USB cable</p>	
Combined	 <p>Room1 + Room2</p> <p>— Ethernet cable — USB cable</p>	

Description of screen

The descriptions provided below are for the example of a screen when the template file is opened in Provisionaire Control.



About the number of RM-CRs and the number of presets

This template file assumes the following:

- Four RM-CRs (maximum according to specifications)
- Ten presets (maximum according to specifications)

About on-screen operations

- Select a device under “Devices”, and then enter the IP address or unit ID beside “Identifier” under “Properties”.
- Select a preset icon in the “Work Area”, and then register or modify any icon under “Properties”.
- By opening the created screen (panel) and selecting a preset icon, you can simultaneously send a preset-switching command to multiple RM-CRs on the network.

Note

- Prepare/customize the RM-CRs, number of presets and icons according to the operating environment. The icons in the template file are examples.
- To save presets, use the Divide/Combine Room function of RM Device Finder. The switching between presets can also be reviewed in RM Device Finder.
- For an overview of the Divide/Combine Room function, refer to the explanation in the RM-CR Reference Manual.
- For RM Device Finder operating procedures, refer to the User Guide included with RM Device Finder.

Yamaha Downloads
U.S.A. and Canada:
<https://uc.yamaha.com/support/>
Other Countries:
<https://download.yamaha.com/>

@2024 Yamaha Corporation
Published 01/2024
YJ-A0