

## Yamaha MOXF6/MOXF8 Editor V1.6.8 for Windows Release Notes

---

### Main Revisions and Enhancements

#### V1.6.3 -> V1.6.8

- Now supports Cubase 9.5 series.
- Now Cubase 6, 7, 8 series are NON-compliant.
- Solved a problem in which the application might be forced to quit occasionally when using the 64 bit PC.
- Fixed some minor problems.

### Minimum System Requirements

#### NOTE

- Note that the system requirements may be slightly different from those described below depending on the particular computer.
- Keep in mind that the software is often updated and the system requirements are subject to change. You can check the latest version information of each program and its system requirements at the following website:

<http://download.yamaha.com>

|                 |  |
|-----------------|--|
| OS              | 64-bit*<br>Windows 7 SP1/ Windows 8/ Windows 10                            |
| DAW Application | Cubase 9 series  |
| Others          | These system requirements conform to those of the DAW applications and OS. |

\* Operation is not guaranteed in the Windows XP mode on Windows XP mode equipped with Windows 7 or the Boot Camp partition on Mac OS.

### Installing the application

1. After the downloaded compressed file is properly extracted, double-click a following file.  
Install MOXF6\_MOXF8 Editor Standalone\_VST.exe
2. Follow the on-screen instructions to install the software.

### For users of Windows 10

#### Starting the application:

Click "All apps" in the Start menu to see the full list of applications. You can start the application by clicking the icon.

## **For users of Windows 8**

### **Starting the application:**

Once the application is successfully installed, an icon of the application will be in your Windows 8 Start screen. You can start the application by clicking the icon.

### **NOTE**

If the icon is not listed, right-click an empty area of the Start screen and select "All apps." Then select the application icon from the application list.

### **Uninstalling the application:**

1. Right-click the application you wish to remove in the Windows 8 Start screen. If it's not listed, right click an empty area of the screen and select "All apps."
2. A check will be placed on the application you selected. Select the "Uninstall" option that appears at the bottom of the screen.

## **Update History**

### **V1.6.1 -> V1.6.3**

- Now supports Cubase 7.5.
- Now supports Windows 8.1.
- Fixed some minor problems.

---

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

© 2013 Yamaha Corporation All Rights Reserved.