

# I.A.M. ARRANGER.



**DISCOVER YOUR  
ARRANGER WORKSTATION**

PSR-**SX920**

PSR-**SX720**

# I.A.M. ARRANGER.

Yamaha entered the high-end electronic keyboard market in 1984, introducing the PS-6100. This innovative instrument allowed players to perform alongside virtual musicians, all controlled from a single keyboard. The right hand played the melody, while the left hand handled chords and accompaniment. Players could also choose from various rhythm

patterns, including drums, bass, and basic accompaniments for added versatility. Today's Arranger Workstations are equipped with cutting-edge technology and features, offering access to some of the world's most powerful music-making tools. Packed with creative options, they allow musicians to express themselves in any way they choose.

## WHO IS ARRANGER?



### HOBBIEST

Playing their favourite songs at home for pleasure.



### SONGWRITER

Writing songs easily and creating arrangements without the hassle of connecting computers and separate keyboards.



### PERFORMER

Controlling and performing on stage as single entertainer or in a band by using high quality sound and professional on-board tools and features.

Building on the success of the Genos2, the new PSR-SX920 and PSR-SX720 continue to push the boundaries of Arranger Workstations, in terms of sound and versatility. Featuring the latest

Super Articulation technologies and new Crossfade Portamento, the new PSR-SX infuse your performances with expressive dynamics and emotional depth.

[LEARN MORE](#)





# OVERVIEW OF KEY FEATURES IN PSR-SX920 & PSR-SX720

## REINFORCEMENT OF EXPRESSIVE ABILITY

Controlling and performing on stage as single entertainer or in a band by using high quality sound and professional on-board tools and features.

## RESPONSE TO DIVERSE MUSIC

Beat setting for each style section, Pre-Install contents.

## USABILITY IMPROVEMENT

UI improvement of VOICE EDIT, button contrast improvement, Additional Assignable Button, Improvement of layout of Playlist, MIDI Settings can be saved in Registration Memory, Smart Chord, Panel Reset



## ACCESSORIES, APPS & TOOLS

New keyboard bag SC-KB650, EXPANSION EXPLORER App, MIDI Song to Style converter



## BONUS CONTENT AFTER REGISTRATION

Bonus Playlist data and converted Expansion Packs

## REGISTRATION NOW!

For all the Bonus Content and Playlist register your new PSR-SX920 or PSR-SX720.

[REGISTER YOUR NEW ARRANGER](#)






# DISCOVER & PLAYLIST

## PSR-SX920 & PSR-SX720



No matter your musical background, the 'Discover' Expansion Pack makes it easier to explore and master your PSR-SX920 and PSR-SX720. This pack includes 16 Registration Memory banks that highlight key voices and DSP effects. Simply select a Registration Memory and enjoy the enhanced sound. Additionally, five more Registration Memory banks help you discover standout features with ease.



To explore the full musical range of the PSR-SX920 and PSR-SX720, the 'Bonus Playlist' Expansion Pack offers two Registration Memory banks for each on-board Style. Plus, experience the powerful 'Playlist' feature, with one comprehensive Playlist containing all Registration Memory data, allowing you to jump alphabetically through records. Each style category also comes with its own dedicated Playlist for easy navigation.



### HOW TO INSTALL EXPANSION CONTENT


1. Visit the Yamaha Music Hub (button) to create an account and register your PSR-SX920 or PSR-SX720.
2. Under 'MY PRODUCTS,' you'll find an 'Exclusive Downloads' button that gives you access to Expansion Packs.
3. Once downloaded, each pack comes in a ZIP file containing a PPF file for use with the Yamaha Expansion Manager, and a PPI file for direct installation on your PSR-SX.

**Please note:** using the PPI file will overwrite any previously installed content in the 'Expansion' area.



Here we go!

VISIT YAMAHA  
MUSIC HUB


Copy the PPI installation file on a USB memory stick and plug it on your PSR-SX. Tap on "MENU", then on "MENU2" and select "Expansion". Then move on by tapping on "Pack Installation".



You will find the data you copied on the USB memory stick. So tap on "Discover PSR-SX920" or "Discover PSR-SX720" and confirm the message with "OK". As said, current content on "Expansion" area will be removed.




Start the installation with “OK” and confirm. The installation might take some minutes. Once it’s done, confirm again with “OK” and the PSR-SX will re-start automatically.



The software is now installed on your PSR-SX920 or PSR-SX720.

Tap on both “REGIST BANK SELECT +” and “-“ at the same time, then select “User” in the screen and tap on “Expansion”. Now you will find the packs you installed on your PSR-SX.



Inside the folder “Discover PSR-SX920” or “Discover PSR-SX720”, you will find on up top 3 pages 21 Registration Memory Banks with the content below:

## PSR-SX920

CATEGORY	Registration 1	Registration 2	Registration 3	Registration 4	Registration 5	Registration 6	Registration 7	Registration 8
001 Piano	CFX ConcertGrand	C7PopGrand	U3Upright	SaloonUpright	C7SuperstarGrand	CFXOneOctave	CFX CocktailGrand	C7CarillionPad
002 E.Piano	70sSuitcaseClean	70sSuitcasePhase	70sSuitcasePan	70sVintageEP	70sSuitcasePan	DX Production	DX Sparkle	DX Dream
003 Organ 1	JazzStandard	JazzSquabble	GospelOrgan	BalladOrgan	UpsideDownSmile	RockOrgan	EuroPops	EuroReeds
004 Organ 2	HomeTheatreOrgan	TheatreOrganMix2	LieblichGedackt	Diapason	Claribel&Flute	SoftReeds	GrandJeu	ConcertOrganTutti
005 Strings	KinoStrings	KinoStringsSlow	TheatreOrchestra	OrchestraTutti	JazzViolin	ClassicalCello	KinoStringsBasses	KinoStringsTension
006 Brass	Flugelhorn	BigBandTrumpet	MuteTrumpet	PopHornsShake	PopHornsCresc	PopHornsFall SW	SforzandoFall	80sSynthBrassStab
007 Woodwind	BalladSopranoSax	TenorSax	Clarinet	RomanticClarinet	OrchestraFlute	MOR Oboe	IrishPipesAir	PanPipes
008 Choir	BoysChoirOoh	BoysChoirOh-Ah SW	JazzScatVocals SW	Who-Are-You SW	What-Should-We-Do SW	Do-Be-Do-Be SW	GospelVocalsHmm	GospelVocalsWow
009 A.Guitar	ConcertGuitar	FlamencoGuitar	SteelThumbPick	D-FolkGuitar	FolkGuitarDoubled	12StringPicked	LatinAmpedGuitar	ResonatorGuitar
010 E.Guitar	SingleCoilClean	BluesyNight	BrightBlues	OverdriveWahWah	FunkSlap	RoughFingers	50sVintageFull	60sGuitarHero
011 Pad	SoundPictures	AllOrNothing	WhisperGallery	OberSweep	PadVoices	SpectrumPad	GalaxyPad	MorningDew
012 Synth	DancyHook	WheelTech JS	HandsUp!	TriPicks	PizzuDanceChords	WaveDancer	HouseOfChordZ	PitchyPatch
013 Accordion	JazzCassotto	ScotsAccordion	TangoAccordion	SteirischeHarmonika	AccordionClarinet	BajanAccordion	SuperMusette	Bandoneon
014 Drumkit	RockDrumKit	PopDrumKit	VintageOpenKit	VintageMuteKit	JazzStickKit	JazzBrushKit	80sPopKit	SchlagerKit
015 SA2 Voices	SoftTrumpet	BalladSopranoSax	JazzViolin	TenorSax	Clarinet	ClassicTrumpet	BalladClarinet	RomanticClarinet
016 SA+ Voices	KinoStrings	PopHorns	ConcertGuitar	SteelAcousticFinger	60sShadowLead	60sRockHero	50sVintageSolo	ActiveFingerBass
017 Style Dynamics Control	Example1	Example2	Example3	Example4	Example5	Example6	Example7	Example8
018 Chord Looper	BluesShema	Blue Bossa	Knocking on Heavens	Love Me Like You Do	Fly Me To The Moon	Mack The Knife	Vers - Let It Be	Chorus - Let It Be
019 Player-Lyrics-Text	Example1	Example2						
020 Multi Pad	Piano	Strings	A.Guitar	E.Guitar	Organ	Percussion 1	Percussion 2	Bass
021 Arpeggio	Guitar1	Guitar2	Stings	Synth Chords	Synth Arpeggio	Filter&Gate	EDM	Mega Voice



## PSR-SX720

CATEGORY	Registration 1	Registration 2	Registration 3	Registration 4	Registration 5	Registration 6	Registration 7	Registration 8
001 Piano	ConcertGrand	PopGrand	Upright Piano	SaloonUpright	70sBalladUpright	OctavePiano1	CocktailGrand	AmbientUpright
002 E.Piano	StageEP	SuitcaseEP	FunkEP	VintageEP	DX Modern	Pianosphere	DX Sparkle	DX Dream
003 Organ 1	JazzStandard	JazzSquabble	GospelOrgan	BalladOrgan	UpsideDownSmile	RockOrgan	EuroPops	EuroReeds
004 Organ 2	HomeTheatreOrgan	TheatreOrganMix2	LieblichGedackt	Diapason	Claribel&Flute	SoftReeds	GrandJeu	ConcertOrganTutti
005 Strings	SeattleStrings	SeattleSlowStrings	TheatreOrchestra	OrchestraTutti	SoloViolin	Cello	SynthStrings	StringsPad
006 Brass	Flugelhorn	Trumpet	MutedTrumpet2	PopHornsShake	PopHornsCresc	PopHornsFall SW	SforzandoFall	80sSynthBrassStab
007 Woodwind	SopranoSax	TenorSax1	JazzClarinet	GermanRomanticClarinet	OrchestraFlute	MOR Oboe	Moonlight	PanPipes
008 Choir	BoysChoirOoh	BoysChoirOh-Ah SW	JazzScatVocals SW	Who-Are-You SW	What-Should-We-Do SW	Do-Be-Do-Be SW	GospelVocalsHmm	GospelVocalsWow
009 A.Guitar	ConcertGuitar	FlamencoGuitar	SteelGuitar	SteelAcousticPick	12StringStrum	12StringPicked	SemiAcoustic	Mandolin
010 E.Guitar	70sJazzCombo	BluesyNight	BrightBlues	OverdriveWahWah	FunkSlap	RoughFingers	50sVintageFull	SoloAce
011 Pad	SoundPictures	AllOrNothing	WhisperGallery	OberSweep	PadVoices	SpectrumPad	GalaxyPad	MorningDew
012 Synth	DancyHook	WheelTech JS	HandsUp!	TriPicks	PunchLead	ShortUnison	80FMnPolystar	PitchyPatch
013 Accordion	JazzAccordeon	AccordeonClarinet	TangoAccordion	FrenchMusette	CajunAccordeon	Casotto	Steirische	Bandoneon
014 Drumkit	RockDrumKit	PopDrumKit	StandardKit	80sPopKit	80sMuteKit	JazzBrushKitComp	EDM Kit	SchlagerKit
015 SA Voices	BrightTrumpet	BigBandSax	SteelGuitar	OrchestraViola	SpanishGuitar	CiranFingers	AllBarsOut JS	SmoothSaxes
016 SA+ Voices	SeattleStrings	PopHorns	ConcertGuitar	50sVintageSolo	VintageRoundFinger	VintageRoundPick		
017 Style Dynamics Control	Example1	Example2	Example3	Example4	Example5	Example6	Example7	Example8
018 Chord Looper	BluesShema	Blue Bossa	Knocking on Heavens	Love Me Like You Do	Fly Me To The Moon	Mack The Knife	Vers - Let It Be	Chorus - Let It Be
019 Player-Lyrics-Text	Example1	Example2						
020 Multi Pad	Piano	Strings	A.Guitar	E.Guitar	Organ	Percussion 1	Percussion 2	Bass
021 Arpeggio	Guitar1	Guitar2	Stings	Synth Chords1	Melodic Arpeggio	Synth Chord2	Melody Arpeggio	Mega Voice



## > DISCOVER PSR-SX920 & PSR-SX720

# PLAY IT ON: ENJOY THE “PLAYLIST”!

Tap on “PLAYLIST” and then on the field in the top of the display screen. Again, select “User” in the screen, tap on “Expansion” and now on the folder “PSR-SX920\_Bonus\_Playlist” or “PSR-SX720\_Bonus\_Playlist”.



On two pages, you will find the Playlist data. Select your dedicated one by tapping on it and then tap on “X”. Now, you're back in the Playlist screen. By tapping twice on the single records in the list, you will load the Registration Memory bank and immediately can start to play.



## EXPERIENCE THE “DISCOVER” REGISTRATION MEMORIES



### REGISTRATION MEMORY BANK 001-016: VOICES

The respective banks of voices contain the most distinctive voices from the category, with matching DSP effects.


### REGISTRATION MEMORY BANK 017: STYLE DYNAMIC CONTROL

Call up one of the 8 Registration Memories and play the style while you change the dynamics of the style with the left LIVE CONTROL knob.



### REGISTRATION MEMORY BANK 018: CHORD LOOPER


Call up one of the Registration Memory 1 to 8 and start the style. Press the DIRECT ACCESS button and then CHORD LOOPER ON/OFF. The titles of the chord sequences are displayed on the screen.





## REGISTRATION MEMORY BANK 019: PLAYER-LYRICS-TEXT


Call up one of the two registration memory and then press PLAYER. Start both players alternately. Different songs are selected when changing the Registration Memory 1 and 2.




### FOR MIDI SONG PLAYBACK:

#### Song Position

By tapping the song position markers, you can switch to specific positions in the MIDI file. LOOP repeats the selected phrase.




“Score” displays the lead sheet of the MIDI file, “Lyrics” the song text. “Text” displays a linked TXT file which is helpful when making music with Styles, for example. The pedal switches to the respective page.



#### For Audio Playback

“A-B Repeat” sets a loop that is repeated. “Pitch Shift” transposes the audio file. “T.Stretch” changes the tempo of the audio file am “V.Cancel” lowers the volume of the vocal or lead track.



## REGISTRATION MEMORY BANK 020: MULTI PADS

The Registration Memory 1 to 8 contain examples of Multi Pads. Play a chord and the style starts synchronised with the other Multi Pads.



## REGISTRATION MEMORY BANK 021: ARPEGGIO

Call up one of the Registration Memories 1 to 8 and play a chord. You can also start a style. Press DIRECT ACCESS and then HARMONY/ARPEGGIO. The selected arpeggio type is now displayed.



## DISCOVER YOUR NEW ARRANGER WORKSTATION

Discover how to use your new Yamaha Arranger Workstation PSR-SX920 & PSR-SX720, click the button to watch YouTube videos.

WATCH ARRANGER YOUTUBE VIDEOS





Yamaha Music Europe GmbH • Siemensstr. 22-34 • 25462 Rellingen/Germany  
[www.yamaha.com](http://www.yamaha.com)

The descriptions and photos in this brochure are for information only. YAMAHA reserves the right to change the products and technical data at any time without notice. As the technical data may vary from country to country, please obtain information from your Yamaha subsidiary. No liability is accepted for printing errors. Status: October 2024.