

Executive Elite Firmware Version: 1.1.10.643 Product Release Notes

December 29, 2020

New features and improvements in this firmware release:

Summary	Notes
Modifications to front panel UI	RF Power Screen
	 Remove power auto scaling option
	 Remove lowest 2 power settings
	Main Screen
	Remove Cloud Management
Modifications to web UI	Main Page
	Remove Cloud Management
	System Management Tab / RF Power Page
	 Remove power auto scaling option
	 Remove lowest 2 power settings
	System Management Tab / Software Upgrade Page
	 Removed "Check for Latest Version" button
	Added checks for filename selected for download
	 Must be .bundle extension
	 Cannot have CS-700 or FLX-UC in name
	System Management Tab / System Configuration Page
	 If country/region is locked, it is now displayed, but
	cannot be changed
	Audio Management Tab / System Audio Page
	 Add AVB stream configuration for single or multi channels per stream
	Microphone Audio Tab
	Analog output gain max change to +8 dB
	System Management Tab / System Information Page
	Add USB Host Status
	Update support URLs to https://uc.yamaha.com/support/
	Update email to uc-support-SMB@music.yamaha.com
USB Interface enhancements	Advertise as MIC only (remove Speaker descriptors).
	Serial number generated from Elite base serial number.
	Add Telephony HID (mute, hookswitch, etc.) as used by
	Zoom, Teams, etc.
	Add Microsoft UCQ string.
	Host device mute of audio stream.

Issues resolved in this firmware release:

Summary	Notes
AVB stream connections not	The AVB stream connections were not cleared when the
cleared correctly	stream mode (single/multi) was changed.



USB Telephony HID support:

This feature was tested as an audio microphone device against Microsoft Teams and the Zoom client. It functioned properly with both when tested on December 23, 2020.

With Telephony HID support, if the host device has the mics unmuted, the wireless mic user can mute/umute the individual mic. If the host device has the mics muted, then all the wireless mics are muted and locked so the individual mic can not be unmuted by its user. Upon host unmute, the individual mic mute state is restored to the state it was in when the host mute was initiated.